


# Cluster

Cross-shaped Workstation

**NOVAH<sup>®</sup>**



NOVAH System Technology Co.,Ltd.  
Tel: 400-115-1688  
Web: [www.novah.cc](http://www.novah.cc)  
Mail: [int@novah.cc](mailto:int@novah.cc)

**NOVAH<sup>®</sup>**

# Product Parts List



Cross recessed countersunk  
head tapping screw  
(4\*20)



Cross recessed countersunk  
head tapping screw  
(4\*45)



Cross recessed  
milling-end screw  
(M4\*10)



Hexagon socket cylindrical  
head screw  
(M6\*16)



Hexagon socket cylindrical  
head screw  
(M6\*50)



Hexagon socket cylindrical  
head screw  
(Including spring washer)  
(M10\*65)



Tapered support of  
table board  
(NFCA-2002)



Screen routing sheet  
(NF4B-3003)



Conical upper connector  
of beam  
(NFCA-2003)



Conical lower  
connector of beam  
(NFCA-2004)



Flat washer  
(PD06AT3)



Middle leg support  
(NFCE-1106)




Middle legs' upper beam  
end member  
(NFCE-1107)



Beam support  
(NFCE-1108)


# Step 1

## 1. Install door-like side foot




# Step 2

## 1. Install the middle leg (routing type)




# Step 3

## 1. Install the table leg stand




# Step 4

## 1. Install the countertop, junction box and GATE desktop screen




# Step 5

1.Install the desktop screen



# Step 6

1.The installation is complete



Make sure to fasten the screws of flat guard board to avoid excessive gap and abnormal noise!