
Cluster

H-leg Conference Table (Two-section)










Product Parts List

()) (P) ())))))))) Cross countersunk self-tapping Cross big flat head Cross countersunk self-tapping screw 4*16 screw 4*45 self-tapping screws 5*20 Hexagon socket cylindrical Hexagon socket cylindrical Hexagon socket cylindrical head screw M6*16 head screw M6*50 head screw M10*60, including spring washer + flat washer Tapered support of Upper conical connector Hexagon socket cylindrical table board of beam head screw M8*30 Lower conical connector Connecting sheet of of beam table board

Step 1

1.Cluster H-leg conference table, beam bracket A and bracket B I.Paste single-sided magic tape on the bottom surface at the joint of beam;

II.While connecting the beam bracket, the joint protrudes by about 5mm; Tighten them with screws and adjust to achieve alignment




Step 2

1.Install the H-leg, beam bracket and thread the power cord


I.The leg and beam bracket are connected firmly with screws, upper and lower conical connector;

II.The steel frame is placed properly. Remove the trim of leg column and thread the power cord



Step 3

1.Install the middle support of beam, middle support of upper beam of leg and steel socket panel




Step 4

1.Install the table leg stand and table board


I.Firstly, correctly assemble the table boards with four connecting sheets of table board;

II. Secondly, connect the steel kickstand and table board with screws



Step 5

1.Complete the power track and adapter
I.First, open the slender strip cover in the middle of power track;
II.Then, connect the power track and table board with screws
III.Install the slender strip cover after fixing the power track;
IV.Install the adapter



Step 6

1.The installation is complete

