


Cluster

H-leg Conference Table (One-section)

NOVAH[®]



NOVAH System Technology Co.,Ltd.
Tel: 400-115-1688
Web: www.novah.cc
Mail: int@novah.cc

NOVAH[®]

Product Parts List



Cross countersunk self-tapping
screw 4*16



Cross countersunk self-tapping
screw 4*45



Cross big flat head
self-tapping screws 5*20



Hexagon socket cylindrical
head screw M6*16



Hexagon socket cylindrical
head screw M6*50



Tapered support of
table board




Upper conical connector
of beam



Lower conical connector
of beam

Step 1

1.Install Cluster H-shaped side leg and beam




Step 2

1.Install the middle support of beam

I.Middle support of beam and side leg's middle support of beam are arranged properly;

II.The steel frame is placed properly; Remove the trim of leg column and thread the power cord




Step 3

1.Install the table leg stand and table board

I.Firstly, correctly assemble the table boards with four connecting sheets of table board;

II.Secondly,connect the steel kickstand and table board with screws




Step 4

1.Install steel junction box

I.First, install the steel socket panel and steel junction box;

II.Then, connect the steel junction box and table board



Step 5


1.Complete the power track and adapter

I.First, open the slender strip cover in the middle of power track;

II.Then, connect the power track and table board with screws;

III.Install the slender strip cover after fixing the power track;

IV.Install the adapter



Step 6

1.The installation is complete

