


Rocky


NOVAH®




NOVAH System Technology Co.,Ltd.
Tel: 400-115-1688
Web: www.novah.cc
Mail: int@novah.cc

NOVAH®

Product Parts List




1x




1x




1x



2x



1x



1x



M6*16

8x



M8*30

2x



5*20

4x



5*30

6x



T4*16

4x



K*16

3x




4*5

1x





1x



4x



Step 1

Install the casters to the bottom stand and secure the stand to the bottom cross member




Step 2

Insert the support rod into the base and fix it with screws




Step 3

Install the bottom beam of the fixed caster to the base




Step 4

Install the support rod interface and the cup holder to the bottom of the table in sequence



Step 5

Install the table top on the support pole



Step 6

The installation is complete

