

Yoko_H

NOVAH[®]



NOVAH System Technology Co.,Ltd.
Tel: 400-115-1688
Web: www.novah.cc
Mail: int@novah.cc

NOVAH[®]

Product Parts List



1x



Lifting Armrest

1x




Fixed Armrest

1x


or



1x




1x



1x



5x



1x



M8*20

3x



M8*2

3x




M8*2

3x



M6*30

6x




M6

1x


Step 1

Insert the casters into the five-star feet successively




Step 2

Place the air pressure rod into the center of the chair feet




Step 3

Install the backrest to the base




Step 4

Fasten the armrest to the seat cushion



Step 5

Insert the top half of the assembled seat and the ring footrest against the gas pressure shaft



Step 6

The installation is complete

