


FourAll

Lounge Low Back 2-seater

NOVAH[®]



NOVAH System Technology Co.,Ltd.
Tel: 400-115-1688
Web: www.novah.cc
Mail: int@novah.cc

NOVAH[®]


Product Parts List

①



(Internal bentwood board
of the seat)

②



(Internal bentwood board
of the back)

③



8x(Fastener B)

④



24x(Cross big flat head
self-tapping screws 4*12-Black)

⑤



8x(Fastener C)

⑥




8x(Fastener A)

⑦




8x(Gasket)

⑧



(External bentwood board
of the seat)

⑨



(External bentwood board
of the back)

Step 1

10



(Low-back frame)

11



8x(Hexagon socket large flat
head screw M6*20
Galvanized)

12



4x(Hexagon socket head
cap screws M6*30
(Galvanized))

13




16x(Cross countersunk
self-tapping screw 4*12
(Galvanized))


14




(Iron connector of
the seat and back)




Step 2




Step 3




Step 4




Step 5



Step 6




Step 7




Step 8

- 1.Put the bentwood board on the fastener A and apply pressure in the direction of the arrow;
- 2.Tap in the direction of the arrow to connect the fastener B to fastener C.



Step 9

- 1.Put the bentwood board on the fastener A and apply pressure in the direction of the arrow;
- 2.Tap in the direction of the arrow to connect the fastener B to fastener C.



Step 10

