


# FourAll

Stool 2-seater

**NOVAH<sup>®</sup>**




NOVAH System Technology Co.,Ltd.  
Tel: 400-115-1688  
Web: [www.novah.cc](http://www.novah.cc)  
Mail: [int@novah.cc](mailto:int@novah.cc)

**NOVAH<sup>®</sup>**


# Product Parts List

①



(Internal bentwood board  
of the seat)

②



(Internal bentwood board  
of the back)

③



8x(Fastener B)

④



24x(Cross big flat head  
self-tapping screws 4\*12-Black)

⑤



8x(Fastener C)

⑥




8x(Fastener A)

⑦



8x(Gasket)

⑧



(External bentwood board  
of the seat)

⑨



(External bentwood board  
of the back)

# Step 1

10



(Chair frame)

11



9x(Hexagon socket large flat head screw M6\*20 Galvanized)

12



4x(Hexagon socket head cap screws M6\*30 (Galvanized))

13




16x(Cross countersunk self-tapping screw 4\*12 (Galvanized))


14




(Iron connector of the seat and back)




# Step 2




# Step 3




# Step 4




# Step 5



## Step 6




## Step 7




# Step 8

- 1.Put the bentwood board on the fastener A and apply pressure in the direction of the arrow;
- 2.Tap in the direction of the arrow to connect the fastener B to fastener C.



# Step 9

- 1.Put the bentwood board on the fastener A and apply pressure in the direction of the arrow;
- 2.Tap in the direction of the arrow to connect the fastener B to fastener C.



# Step 10

