


Lancelot

NOVAH




NOVAH System Technology Co.,Ltd.
Tel: 400-115-1688
Web: www.novah.cc
Mail: int@novah.cc

NOVAH

Product Parts List

①



1X(Round Table Top)

②




1X(Cross Base)

③




1X(Round Table Leg Column)

④



1X(Round Table Framer)

⑤



1X(Round Table Metal Base Cover)

⑥



8X(Socket Head Cap Screws with Flat Washers M8x25)

⑦



17X(Countersunk Self-Tapping Screws 5x20)

⑧



4X(Hexagon Socket Flat Head Screws 6x12)


⑨



4X(Cluster Leveling Feet Short Screws)


Step 1

Install Base and Leg Column




Step 2

Place Metal Base Cover




Step 3

Install Table Frame




Step 4

Install Height-Adjustment Socket and Table Top




Step 5

Install Base Cover



1



2

Step 6

Complete

