Lancelot

Dual-Column Conference Table
Without Privacy Panel

NOVAH

NOVAH

Product Parts List

①
1x(V-Shape Table Top Assembly – W3200)

②
1x(V-Shape Table Frame – W3200)

③
1x(Center Base Cover (No Panel) – Left Side – W3200)

④
1x(Center Base Cover (No Panel) – Right Side – W3200)

⑤
1x(Long Table Leg Crossbeam)

⑥
2x(Leg Columns)

⑦
1x(End Base Cover Type 2 (No Panel))

⑧
1x(End Base Cover Type 1 (No Panel))

⑨
2x(V-Shape Base Feet)

(10)

8x(Pan Head Phillips Screws with Flat Washers M8×20)

(11)

16x(Socket Head Cap Screws with Flat Washers M8×25)

(12)

17x(Countersunk Phillips Self-Tapping Screws 5×20)

(13)

4x(Countersunk Phillips Self-Tapping Screws 6×16)

(14)

14x(Hexagon Socket Flat Head Screws M6×12)

(15)

24x(Countersunk Phillips Self-Tapping Screws 4×20)

(16)

4x(Cluster Leveling Feet – Short Screws)

(17)

3x(Cluster Leveling Feet – Long Screws)

(18)

3x(Table Top Connector Plates)

(19)

3x(Ultra-Thin Table Top Connectors)

Step 1

Install Base Feet

(10)

Step 2

Install Leg Columns

Step 3

Install Table Frame

Step 4

Place and Connect the Table Top
First, position the table top onto the installed frame.
Then, secure it from underneath using the provided connectors.

1

⑲

2

# Step 5

Install Table Top Connector Plates

⑮

Step 6

Install Table Top

⑫

Step 7

Install Center Base Covers

⑬

⑭

Step 8

Install End Base Covers


⑭

Step 9

Power Option 1

Step 10

Power Option 2

Step 11

Complete