

NOVAH®



ZUNA

Guide Book

Headrest Adjustment:

Adjust the headrest forward or backward by pressing the control lever.

To adjust height: Pull the headrest upward to unlock and raise it; lower it to decrease height. When fully lowered, the headrest automatically re-engages the lock.



Armrest Adjustment:



2D Armrests

- Press the height control button to adjust armrest up or down.
- Slide the armrest forward or backward to adjust its depth position.



3D Armrests

- Press the height button to adjust armrest vertically.
- Slide the armrest pad forward or backward for depth adjustment.
- Rotate the armrest pad inward or outward to adjust angle.



4D Armrests

- Adjust height by pressing the control button.
- Slide the armrest pad forward or backward for depth adjustment.
- Rotate the pad to adjust angle.
- Slide the pad laterally (left or right) to adjust width position.

Lumbar Support Adjustment:

Lift the control lever upward to raise the lumbar support. Release to lock in position.

Recline Mechanism Adjustment:



Single-Stage Synchronous Recline

- Lift or lower the seat plate freely by raising/lowering the seat height lever.
- Pull the recline handle to adjust the angle between seat and backrest.
- Rotate the tension knob to adjust spring resistance.



Dual-Stage Gravity Recline

- Adjust seat height using the height lever.
- Pull the recline handle to independently control the angle of the seat and backrest.



Multi-Function 4-Stage Synchronous Recline (Without Seat Depth Adjustment)

- Handle A:** Adjust seat height freely.
- Handle C:** Control the angle of both seat and backrest.
- Handle F:** Quickly adjust spring tension for recline resistance.



Multi-Function 4-Stage Synchronous Recline (With Seat Depth Adjustment)

- Handle A:** Adjust seat height.
- Handle C:** Control seat and backrest angle.
- Handle F:** Quickly adjust recline spring tension.
- Handle G:** Adjust the sliding plate to change seat depth.